

## Instructions for Carbonfiber Shift Paddles Audi A3 8Y, A4/A5 B9 from 2018

**Attention: Disassembly of the airbag can only be done by experienced personell. Thus the removal of the Airbag will not be further described in the following.**

1. Remove the Airbag according to OEM instructions
2. Unplug the shiftpaddle cable L/R
3. Losen the screw holding the shift paddle in place
4. Press the shift paddle towards the speedometer and into the direction of the doors. The paddles are held in place by a hook facing towards the center of the steering wheel.
5. After removing the paddles from the steering wheel, the metal guidance pin needs to be removed. It can only be pushed in one direction (towards the top) as shown in the pictures below. Use a small screwdriver to push the pin out a little and then finish it off with pliers.



6. The top and bottom part can now be seperated.
7. Place the top part into the carbon fiber paddle and carefully press it in until the holes align. Then press the guidance pin back in, if necessary use pliers. Be careful not to scratch the carbon fiber. May use a microfiber towel.
8. Check if the paddle is functioning as intendend and reinstall it in the car in reverse order.